



# PETTER DIESELS

## PH OPERATORS HANDBOOK

Publication No. 355764 Issue 19

### OPERATION

#### Preparing to start a new or overhauled engine


Fill the sump with lubricating oil to the high level mark on the dipstick. If an oil-bath air cleaner is fitted, fill the bowl to the level indicated. If a clutch (Ref. HJG73) is fitted, pour 300 ml into the housing. Lubricate the control linkages.

Lift the decompressor levers (A) and crank the engine fifteen revolutions to help circulate the oil.

Fill the fuel tank and bleed the fuel system. ALWAYS ENSURE FUEL AND OIL CONTAINERS, FUNNELS, ETC. ARE CLEAN BEFORE USE.

#### To bleed the fuel system

Loosen the two vent screws (B) on the fuel filter and tighten when bubble-free fuel leaks



4221

### FONCTIONNEMENT


#### Préparation d'un moteur neuf ou révisé pour la mise en marche

Remplir le carter d'huile de graissage jusqu'au repère supérieur sur la jauge d'huile. Si un filtre à air à bain d'huile est installé, remplir la cuve jusqu'au niveau indiqué. Si un embrayage (HJG73) est installé, verser 300 ml dans le carter. Graisser les tringles de commande.

Soulever les leviers de décompression (A) et faire tourner le moteur quinze fois pour aider à faire circuler l'huile.

Remplir le réservoir à carburant et purger le circuit d'alimentation en carburant.

VEILLER TOUJOURS A CE QUE LES RECIPIENTS, ENTONNOIRS, ETC., EMPLOYES POUR LE CARBURANT ET L'HUILE SOIENT PROPRES AVANT USAGE.



4222

### FUNCIONAMIENTO


#### Preparación de un motor nuevo o reacondicionado para la puesta en marcha

Llenar el cárter de aceite de lubricación hasta el nivel alto marcado en la varilla indicadora. Si hay instalado filtro de aire con baño de aceite, llenar el recipiente hasta el nivel indicado. Si hay instalado embrague (HJG73), echar 300 ml en el cárter del embrague. Lubricar las articulaciones del varillaje de mando.

Levantar las palancas del descompresor (A) y hacer girar el motor quince vueltas para que circule el aceite.

Llenar el depósito del combustible y purgar este sistema.

ANTES DE USAR ENVASES DE COMBUSTIBLE Y ACEITE, EMBUDOS, ETC., CERCIORARSE DE QUE ESTAN LIMPIOS.



4223


## FUNZIONAMENTO

### Preparativi per l'avviamento di un motore nuovo o revisionato

Riempire la coppa di olio lubrificante sino al contrassegno d'alto livello sulla stecca. Se è previsto un filtro d'aria in bagno d'olio, riempire la coppa sino al livello indicato. Se è prevista una frizione (HJG73), versare 300 ml nella sede. Lubrificare i leveraggi di comando. Sollevare le leve di decompressione (A) e impartire a mano quindici giri al motore per facilitare la circolazione dell'olio.

Riempire il serbatoio di combustibile e spurgare l'impianto d'alimentazione.

ACCERTARSI SEMPRE CHE I CONTENITORI COMBUSTIBILE ED OLIO, IMBUTI, ECC. SIANO PULITI PRIMA DELL'USO.



## BEDIENUNGSANLEITUNG


### Vorbereitung zum Anlassen eines neuen oder überholten Motors

Den Sumpf bis zur Hochstandsmarke des Peilstabs mit Schmieröl auffüllen. Falls ein Ölbad-Luftreiniger vorhanden ist, den Topf bis zur ange deuteten Höhe auffüllen. Falls eine Kupplung (HJG73) vorhanden ist, 300 ml in das Gehäuse gießen. Regelstangen schmieren.

Die Dekompressorhebel (A) anheben, und den Motor fünfzehnmal durchdrehen, damit das Öl umlaufen kann.

Den Kraftstofftank füllen, und die Luft aus dem Kraftstofftank ablassen.

STETS DARAUFGAHTEN, DASS KRAFTSTOFF- UND ÖLBEHÄLTER, TRICHTER USW. BEI INBETRIEBNAHME SAUBER SIND.



## BEDIENING


### Voor het starten gereedmaken van een nieuwe of gerevideerde motor

Het carter met smeerolie vullen tot aan de bovenste streep op de oliepeilstok. Als een oliebad-luchtfiler is aangebracht, de kom tot het aangegeven niveau vullen. Indien een koppeling (HJG73) is aangebouwd 300 ml in het huis gieten. Smeer de scharnierpunten van de bedieningsstangen.

De decompressor hefboomen (A) omhoog trekken en de motor vijftien maal draaien om de oliecirculatie aan de gang te krijgen.

Brandstoftank vullen en het brandstofsysteem ontluften.

ZORG ER ALTIJD VOOR DAT BRANDSTOF- EN OLIEBUSSEN, TRECHTERS, ENZ. VOOR HET GEBRUIK GEREINIGD ZIJN.



out. Loosen the vent screw (C) on each injection pump and tighten when bubble-free fuel leaks out. Operate each injection pump priming lever (D) until the injector (E) is heard to operate.

### To start the engine

Check that the air cleaner, fan inlet and all ventilation openings are clear of obstruction. Make sure that all guards are in position.

Top up with lubricating oil and fuel and if possible remove the load from the engine. Lift the overload stop control (F) (painted red) and if applicable set the speed control to full speed (G).

If the engine is cold — operate each injection pump priming lever (D) and when the injector (E) is heard to operate give a further six strokes and leave the levers down.

If the engine is hot — raise the priming and decompressor levers (D & A) to the vertical position and slowly crank the engine for fifteen revolutions to expel hot air before starting. Lower the levers.

Raise the decompressor levers (A) and crank the engine as fast as possible or operate the starter motor. Lower one lever while cranking fast and the other when the engine fires.

THE STARTING HANDLE SHOULD BE HELD FIRMLY WITH THE THUMB ON TOP OF THE GRIP AND NOT ROUND IT.

Remove the starting handle.

With a new or overhauled engine, stop after a few minutes running and top up with lubricating oil.

When operating in temperatures below about  $-5^{\circ}\text{C}$  an SAE 5W lubricating oil may be required. A cold starting aid may also be required.

KEEP CLEAR OF THE ENGINE WHILE IT IS IN OPERATION.

### To stop the engine

If possible, run on light load for a few minutes and then either raise the injection pump priming levers (D) or move the fuel pump rack (H) to the right until the engine stops.

DO NOT SHUT OFF THE FUEL SUPPLY OR USE THE DECOMPRESSOR LEVERS TO STOP ENGINE.

### Starting and running problems

If the engine fails to start after successive attempts, check for:

- Excessive drag caused by incorrect grade of lubricating oil.
- Lack of compression\*.
- Faulty fuel supply\*\*.

If the engine lacks power, surges, overheats or stops, check for:

- Overheating\*\*\* and/or seizure.
- Choked air cleaner or faulty fuel supply\*\*.
- Lack of compression\*.

If the engine suffers from heavy vibration or knocking, check for:

- Overheating\*\*\*.
- Excessive bearing, piston ring or cylinder bore wear, sticking valves, insufficient bumping clearance, excessive carbon deposit or incorrect timing.
- Misalignment, loose coupling or mounting bolts, or unstable mounting framework.

\* Caused by valves leaking or incorrectly set, leaking cylinder head gasket or injector seating, or excessive piston ring and cylinder bore wear.

\*\* Caused by air or water in the fuel supply, blocked fuel tank cap vent, faulty injector or pump, or incorrect timing.

\*\*\* Caused by lack of ventilation, too much load, lack of engine oil, excessive wear, or choked exhaust.

## ROUTINE MAINTENANCE

Under very dusty conditions or when the engine is run on light loads for long periods, servicing may be required more frequently.

### After the first 20 hours

Drain and refill the sump (J).

Check the tightness of all nuts and bolts when the engine is cold. Use a torque spanner where applicable (K).

Check the valve and decompressor settings. Clean the fuel filter bowl (L) and bleed the system.

### Every 50 hours

Clean and check the air cleaner.

### Every 250 hours

Drain and flush the sump (J).

Wash oil pump strainer (accessible through the crankcase inspection cover (M)) and refill the sump (J).

If an oil filter (N) is fitted, change the element.

Clean carbon from the exhaust system.

Clean the fuel filter bowl (L), the vent hole in the fuel tank cap and bleed the fuel system. Clean and test the fuel injector (E).

Check the tightness of all nuts and bolts when the engine is cold. Use a torque spanner where applicable (K).

Check the valve and decompressor settings. Lubricate the control linkages.

Check, clean and lubricate the handle starting equipment.

### Every 500 hours

Change the fuel filter element and paper air-cleaner element.

### Every 2000 hours

Wash out the fuel tank.

Decarbonise and fit a new cylinder head gasket.

Depending on how the engine has been used and maintained it may be necessary to check the large end and main bearings and the piston rings.

### To adjust the valve clearances

With the engine cold and the valves closed, loosen the locknut (V) and turn the rocker adjusting screw (W) to set the gap (X) to 0.1 mm. Tighten the locknut and re-check the gap.

To set the decompressor, move the lever to the vertical position, loosen the locknut (Y) and turn the adjusting screw (Z) until it just touches the exhaust valve rocker. Screw down another half turn and tighten the locknut.

## GENERAL MAINTENANCE

### To test the fuel injector

Absolute cleanliness is essential when handling injection equipment.

Disconnect the pipe fittings (P & Q) at the injector (E), remove the flange nuts and carefully lever the injector out of its cooling sleeve.

Reconnect the high pressure fuel pipe (P) and point the injector nozzle (R) away from both the engine and the operator. The exterior of the injector can be cleaned with a brass wire brush and the spray holes cleared of soft carbon with the pricker supplied.

Operate the injection pump priming lever (D) and check that three fine mist sprays are ejected from the nozzle (R) and stop suddenly. If the nozzle does not spray, emits squirts of fuel or dribbles, change the injector.

**THE SPRAY IS EMITTED WITH CONSIDERABLE FORCE AND MUST NOT BE DIRECTED AT ANY EXPOSED PART OF THE BODY, AS IT WILL PENETRATE THE SKIN.**

Replace the injector and loosely fit the flange nuts. Fit the high pressure fuel pipe (P) and tighten the union nut finger tight plus one third of a turn with a spanner. Tighten the injector flange nuts evenly and reconnect the leak-off pipe (Q).

### Decarbonising

Remove and store all components in sequence so that they can be refitted in their original location.


Remove the cylinder cowl, the inlet and exhaust manifolds and disconnect the oil and fuel pipes. Carefully remove the fuel injector, the rocker box cover and the complete rocker box assembly. Withdraw the push rods and remove the pushrod tubes (S). The cylinder head can then be removed.

Clean the manifolds. With the piston at TDC remove any carbon from the piston crown. Remove the valves and clean the cylinder head, the exhaust and inlet ports and the valve guide recesses. Badly pitted or distorted valves should be changed. Grind in the valves.

When replacing the cylinder head fit a new cylinder head gasket. Make sure the push rod tubes (S) are fitted with the stepped end down and the oil seals (T) and joint washers (U) are in good condition and seating properly. On twin cylinder engines, ensure that the manifold mounting faces are square and in line.


Screw down the nuts finger tight, then using a torque spanner set to 83 N m tighten in a diagonal sequence until all the nuts are tight. After completing re-assembly, check the valve clearances and the decompressor setting. Recheck the cylinder head nuts for tightness when the engine has run for about 20 hours and is cold.





**PLATE B – continued**

Ref. No.	Description	1 Cyl	2 Cyl
HJB66	Nut	6	12
HJB69	Cylinder	1	2
AJB74	Joint—Cylinder (0.38mm)	As required	
AJB74a	Joint—Cylinder (0.13mm)	As required	
AJB74b	Joint—Cylinder (0.08mm)	As required	
JB83	Tube—Breather	1	2
HJB85a	Sleeve—Nozzle	1	2
CB88	Base—Push Rod Tube	1	2
CB89	Joint—Push Rod Tube Base	1	2
AJB90	Tube—Push Rod (Upper)	2	4
CB91	Tube—Push Rod (Lower)	2	4
AJB92	Spring—Push Rod Tube	2	4
AJB93	Adaptor—Push Rod Tube	4	8
AJB94	Oil Seal—Push Rod Tube	4	8
CB95	Joint Washer—Push Rod Tube Adaptor	4	8
CB113	Cover—Push Rod Tube	2	4
MJB147	Dog—Decompressor (Linked Decompressors)	—	2
HJB265	Injector—Fuel (including Nozzle and Holder)	1	2
*HJB265a	Injector—Fuel (including Nozzle and Holder) (900-1000 r/min)	1	2



**PLATE C—CRANKSHAFT AND PISTON**

Ref. No.	Description	1 Cyl	2 Cyl
AJC1	Flywheel (Up to 1650 r/min)	1	1
*AJC1c	Flywheel (1651 to 2000 r/min)	1	1
HJC2	Pulley—Dynamo Driving	1	1
AJC3	Key—Flywheel	1	1
JC5	Oil Seal	1	1
HJC6	Housing—Main Bearing (Flywheel end)	1	1
JC7	Joint—Main Bearing Housing	1	1
HJC8	Bearing—Main (Flywheel end) (Standard)	1	1
*HJC8a	Bearing—Main (Flywheel end) (0.25mm Undersize)	1	1
*HJC8b	Bearing—Main (Flywheel end) (0.51mm Undersize)	1	1
*HJC8c	Bearing—Main (Flywheel end) (0.76mm Undersize)	1	1
*HJC8d	Bearing—Main (Flywheel end) (1.02mm Undersize)	1	1
HJC9	Crankshaft	1	—
HJC9a	Crankshaft	—	1
HJC10	Piston Assembly, complete with Rings, Pin and Circlips (Standard)	1	2
*HJC10b	Piston Assembly, complete with Rings, Pin and Circlips (0.51mm Oversize)	1	2
*HJC10d	Piston Assembly, complete with Rings, Pin and Circlips (1.02mm Oversize)	1	2
JC14	Circlip—Gudgeon Pin	2	4
HJC15	Gudgeon Pin	1	2
CC16	Bush—Small End	1	2
WJC17	Connecting Rod Assembly, complete with Small End Bush, Large End Bearing and Bolts	1	2
HJC18	Bolt—Large End	2	4
CC21	Bearing—Large End	1 pr.	2 prs.
*CC21a	Bearing—Large End (0.25mm Undersize)	1 pr.	2 prs.
*CC21b	Bearing—Large End (0.51mm Undersize)	1 pr.	2 prs.
*CC21c	Bearing—Large End (0.76mm Undersize)	1 pr.	2 prs.
*CC21d	Bearing—Large End (1.02mm Undersize)	1 pr.	2 prs.
HJC23	Washer—Crankshaft Thrust	2	2
HJC24	Housing—Main Bearing (Gear end)	1	1
JC27	Gearwheel—Crankshaft	1	—
*HJC27	Gearwheel—Crankshaft	—	1
JC27a	Gearwheel and Oil Thrower (SAE 5 Adaptor)	1	—
*HJC27a	Gearwheel and Oil Thrower (SAE 5 Adaptor)	—	1
JC28	Plate—Gearwheel Retaining	1	1
HJC28	Plate—Gearwheel Retaining (SAE 5 Adaptor)	1	1









**PLATE F – continued**

Ref. No.	Description	1 Cyl	2 Cyl
CF515	Guard—Shaft (Electric Starting) ... ..	1	1
ZPF515	Guard—Starting Shaft (Flywheel end) ... ..	1	1
ZPF517	Chain—Guard ... ..	1	1
AJF518	Guard—Flywheel (Standard Rotation) ... ..	1	1
*AJF518a	Guard—Flywheel (Reverse Rotation) ... ..	1	1
AJF518b	Guard—Flywheel (Electric Starting—Standard Rotation) ... ..	1	1
AJF519	Setscrew—Flywheel Guard ... ..	4	4
AJF519	Setscrew—Flywheel Guard (Electric Starting) ... ..	2	2
702201	Screw, phosphated, M5 x 12mm		




**PLATE G—CLUTCH**

Ref. No.	Description	1 Cyl	2 Cyl
AJG1	Flange—Clutch Driving ... ..	1	1
AJG2	Bearing—Roller ... ..	1	1
AJG4	Toggle ... ..	3	3
JG5	Pin—Toggle ... ..	3	3
JG8	Seal—Driving Flange Screw ... ..	4	4
AJG10	Plate—Outer ... ..	1	1
AJG11	Plate—Driven ... ..	2	2
AJG12	Plate—Driving ... ..	3	3
AJG13	Plate—Inner ... ..	1	1
AJG14	Ring—Adjusting ... ..	1	1
AJG15	Shaft—Clutch ... ..	1	1
AJG16	Sleeve—Sliding ... ..	1	1
AJG19	Bearing—Ball ... ..	1	1
JG24	Dowel—Driving Flange ... ..	1	1
JG25	Joint—Adaptor Plate (Mk IV) ... ..	1	1
*JG25a	Joint—Adaptor Plate (Mk III) ... ..	1	1
JG26	Plate—Adaptor ... ..	1	1
JG29	Plate—Spigot ... ..	1	1
AJG30	Housing—Clutch ... ..	1	1
JG31	Joint—Clutch Housing ... ..	1	1
JG32	Cover—Clutch Housing ... ..	1	1
JG33	Joint—Clutch Housing Cover ... ..	1	1
AJG36	Lever—Clutch Operating ... ..	1	1
AJG37	Shaft—Yoke ... ..	1	1
AJG38	Yoke ... ..	1	1
AJG40	Thrust Ring Assembly ... ..	1	1
AJG48	Housing—Oil Seal ... ..	1	1
AJG50	Joint—Oil Seal Housing ... ..	1	1
AJG69	Oil Seal—Yoke Shaft ... ..	1	1
AJG70	Core Plug ... ..	1	1
JG71	Grubscrew ... ..	1	1
JG87	Washer—Toggle Pin ... ..	6	6
JG88	Spring—Toggle ... ..	3	3
AJG90	Tabwasher—Yoke Bolt ... ..	1	1








## PLATE L—STARTING

Ref. No.	Description	1 Cyl	2 Cyl
JL1	Starting Handle Assembly, complete with Spring, Pawl and Pin (Clockwise) ... ..	1	1
*JL1a	Starting Handle Assembly, complete with Spring, Pawl and Pin (Anticlockwise) ... ..	1	1
JL3	Spring—Starting Handle Pawl ... ..	1	1
JL7	Pin—Starting Handle Pawl ... ..	1	1
AJL8	Flywheel and Gear Ring (Up to 1650 r/min—Standard Rotation) ... ..	1	1
*AJL8a	Flywheel and Gear Ring (Up to 1650 r/min—Reverse Rotation) ... ..	1	1
*AJL8d	Flywheel and Gear Ring (1651 to 2000 r/min—Standard Rotation) ... ..	1	1
*AJL8e	Flywheel and Gear Ring (1651 to 2000 r/min—Reverse Rotation) ... ..	1	1
AJL9	Starter Motor (Standard Rotation) ... ..	1	1
*AJL9a	Starter Motor (Reverse Rotation) ... ..	1	1
AJL10b	Bracket—Starter Motor ... ..	1	1
AJL12	Dipstick and Oil Filler Cap (Electric Starting) ... ..	1	1
JL19b	Dynamo (Standard Rotation) ... ..	1	1
*JL19c	Dynamo (Reverse Rotation) ... ..	1	1
AJL20b	Strap—Dynamo Adjusting ... ..	1	1
HJL25	Spacer—Dynamo Hinge (Belt Guard) ... ..	1	1
AJL25b	Spacer—Dynamo Hinge ... ..	2	2
JL26c	Rod—Dynamo Hinge ... ..	1	1
WCL29	Pulley—Dynamo ... ..	1	1
HJL30a	Belt—Dynamo ... ..	1	1
AJL31b	Panel—Instrument ... ..	1	1
AJL36	Bracket—Instrument Panel ... ..	2	2
JL37	Mounting—Instrument Panel ... ..	4	4
JL40	Nut—Panel Mounting (Self-locking) ... ..	6	6
JL41a	Regulator ... ..	1	1
JL43a	Ammeter ... ..	1	1
VPL44	Switch—Starter ... ..	1	1
AJL46	Bracket—Fan Cowling (Electric Starting—Standard Rotation) ... ..	1	1
AJL46a	Bracket—Fan Cowling (Electric Starting—Standard Rotation) ... ..	1	1
*AJL46b	Bracket—Fan Cowling (Electric Starting—Reverse Rotation) ... ..	1	1


## PLATE L — continued

Ref. No.	Description	1 Cyl	2 Cyl
*AJL46c	Bracket—Fan Cowling (Electric Starting—Reverse Rotation) ... ..	1	1
JL109	Pawl—Starting Handle ... ..	1	1
*HL159	Cable Harness ... ..	1	1
*JL163	Grommet ... ..	1	1
*JL163a	Grommet ... ..	1	1



## FUEL FILTER ASE64

Ref. No.	Description
ASE64/4	Head
ASE64/5	Bowl
ASE64/6	Element
ASE64/11	Bolt—Centre
HJZ14	Spare Parts Pack, consisting of:
ASE64/1	Joint Washer—Element
ASE64/2	Seal—Bowl
ASE64/7	Screw—Vent
ASE64/8	Washer—Vent Screw
ASE64/12	Washer—Centre Bolt
ASE64/13	Spring—Centre Bolt
ASE64/14	Seal—Centre Bolt (Lower)
ASE64/15	Seal—Centre Bolt (Upper)



## OIL FILTER HK81 & HK81a

Ref. No.	Description	
	One-cylinder engine	Two-cylinder engine
JK81/2	JK81/2	...
HK81/3	HK81/3	...
HK81/4	HK81/4	...
VPK81/5	JK81/5	...
VPK81/6	JK81/6	...
HK81/11	HK81a/11	...
VPK81/12	VPK81/12	...
JK81/13	JK81/13	...
JK81/15	JK81/15	...
JK81/16	JK81/16	...
JK81/17	JK81/17	...
JK81/19	JK81a/19	...
CK81/22	CK81/22	...
HK81/23	HK81/23	...
HK81/24	HK81/24	...
	Seal—Sump (Top)	
	Circlip—Centre Bolt	
	Head	
	Sump	
	Element	
	Bolt—Centre	
	Seal—Sump (Bottom)	
	Spring—Centre Bolt	
	Guide—Element	
	Seal—Centre Bolt	
	Washer—Centre Bolt	
	Collar—Sump	
	Engine Relief Valve Assembly	
	Washer—Engine Relief Valve	
	Seal—Engine Relief Valve	

NOTE: A Sump Seal (Top), JK81/2, is included with each Element VPK81/6 and JK81/6

## AIR CLEANER, FUEL AND OIL FILTER ELEMENT PACKS

Ref. No.	Description	1 Cyl	2 Cyl
CZ12	Element Pack—Air Cleaner ...	1	1
	Consisting of:		
	CF423 Element—Air Cleaner ...	4	4
HZ10	Element Pack—Fuel Filter ...	1	1
	Consisting of:		
	JE64/6a Element—Fuel Filter ...	4	4
JZ11	Element Pack—Oil Filter ...	1	—
JZ11b	Element Pack—Oil Filter ...	—	1
	Consisting of:		
	VPK81/6 Element—Oil Filter ...	8	—
	JK81/6 Element—Oil Filter ...	—	8

## SETS OF JOINTS

Ref. No.	Description	1 Cyl	2 Cyl
AJZ2	Decarbonising Set of Joints ...	1	2
	Consisting of: (See Plates B and F)		
	JB4 Joint—Rocker Box Cover ...	1	2
	JB27 Joint—Rocker Box ...	1	2
	JB47 Gasket—Exhaust and Inlet Manifold ...	2	4
	AJB58a Gasket—Cylinder Head ...	1	2
	CB89 Joint—Push Rod Tube Base ...	1	2
	AJB94 Oil Seal—Push Rod Tube ...	4	8
	CB95 Joint Washer—Push Rod Tube Adaptor ...	4	8
	JF38 Joint—Silencer Flange ...	1	2
HJZ3	Conversion Set of Joints ...	1	1
	Consisting of (See Plates A, B, C, D, E and K)		
	JA20 Joint—Fuel Pump Bracket Cover ...	2	2
	JA27 Joint—Fuel Pump Bracket ...	2	2
	JA42 Joint—Inspection and Oil Filler Covers ...	2	2
	JA45 Joint—Oil Filter Cup ...	1	1
	JA49 Joint—Gear Cover Plate ...	1	1
	JA56 Joint—Gear Cover ...	1	1
	JA61 Joint—Gear Cover Blanking Plate ...	1	1
	JB7 Washer—Decompressor Shaft ...	4	4
	JB31 Washer—Rocker Shift ...	5	5
	JC7 Joint—Main Bearing Housing ...	1	1
	JD21 Joint—Governor Fulcrum Bracket ...	1	1
	JD23 Joint—Governor Fulcrum Bracket Plate ...	1	1
	JD28 Joint—Extension Shaft Bearing Housing ...	1	1
	CK34 Joint—Oil Pump ...	1	1
	JK82 Joint—Relief Valve Adaptor ...	1	1
	CK82a Joint—Oil Distribution Bracket ...	1	1
	843003 Joint Washer 7.9mm (Fibre) ...	1	1
	843004 Joint Washer 9.5mm (Fibre) ...	3	3
	843005 Joint Washer 12.7mm (Fibre) ...	5	5
	843104 Joint Washer 9.5mm (Copper) ...	14	14
	843106 Joint Washer 15.9mm (Copper) ...	1	1

## SPEEDER SPRING DETAILS

Ref. No.	Colour	Position	Engine Speed
JA6e	Red/Aluminium	Bands	900—1000
JA6c	Red/Yellow	Bands	1100—1250
JA6	Red/Orange	Bands	1400—1550
JA6f	Red/Black	Bands	1551—1650
tJA6	Red/Orange	Bands	1741—1800
tJA6j	Blue/Brown	Ends	1901—2000
MJD44	Yellow/Black	Bands	Variable Speed

tFor speeds between 1651 and 2000 rev/min a High Speed Flywheel (see Plates C and L) and Governor Springs, JD6a (1651 to 1800 r/min) or JD6b (1801 to 2000 r/min) must be used.

### HEALTH AND SAFETY

TO PROMOTE SAFETY AND TO AVOID RISK TO HEALTH, USERS OF PETER DIESEL ENGINES SHOULD OBSERVE THE FOLLOWING PRECAUTIONS:

ENSURE THAT THE ENGINE IS CORRECTLY INSTALLED, OPERATED AND MAINTAINED. ALWAYS FOLLOW MAKERS' INSTRUCTIONS.

BEFORE STARTING THE ENGINE, REMOVE AS MUCH OF THE LOAD AS POSSIBLE.

WHEN USING A STARTING ROPE, DO NOT WIND THE ROPE ROUND HAND OR WRIST. MAKE SURE THE ROPE IS NOT TANGLED OR FRAYED.

WHEN USING A STARTING HANDLE, HOLD THE HANDLE FIRMLY WITH THE THUMB ON TOP OF THE GRIP AND NOT ROUND IT. KEEP THE HANDLE AND SHAFT CLEAN AND LUBRICATED TO ENSURE EASY WITHDRAWAL OF HANDLE.

DO NOT REMOVE GUARDS.

KEEP CLEAR OF HOT, MOVING OR ELECTRICAL PARTS.

IF THE ENGINE IS INSTALLED IN AN ENCLOSED SPACE, VENT THE EXHAUST FUMES TO ATMOSPHERE.

WHEN TESTING FUEL INJECTORS, DO NOT DIRECT THE SPRAY AT ANY EXPOSED PART OF THE BODY — IT CAN PENETRATE THE SKIN.

Publication No. 355791

# GENERAL INFORMATION

Engine rotation (standard)	... ..	Clockwise looking on the flywheel
Fuel	... ..	Light distillate diesel fuel, gas oil or DERV to BS 2869 Class A1 or A2
Fuel tank capacity (standard)	... ..	6.8 litre
Injector release pressure	900–1099 r/min ...	155 bar ± 2%
	1100–2000 r/min ...	217 bar ± 2%
Lubricating oil	... ..	Heavy duty to API : CC
Below 5°C	... ..	SAE 10W or 10W/30
5°C to 30°C	... ..	SAE 20W/20
Above 30°C	... ..	SAE 30
Lubricating oil capacity	PH1	2.8 litre
	PH1 with filter	3.4 litre
	PH2	5.7 litre
	PH2 with filter	6.5 litre
Lubricating oil pressure at full speed	... ..	2.4 bar minimum
Cylinder bore diameter (standard)	... ..	87.465/87.491 mm
Cylinder reboring diameters	... ..	0.51 mm oversize
		1.02 mm oversize
Crankshaft journal diameters (standard)		
Main journal	... ..	60.287/60.274 mm
Crankpin and intermediate journal	... ..	60.325/60.312 mm
Crankshaft journal regrinding diameters	... ..	0.25 mm undersize
(Main journal, crankpin and intermediate journal)		0.51 mm undersize
		0.76 mm undersize
		1.02 mm undersize
Bumping clearance	... ..	0.91/1.07 mm
Valve clearance (cold)	... ..	0.1 mm

Petter policy is one of continuous improvement and accordingly the company reserves the right to alter the specification and information given in this book without prior notice. In compiling this book every care has been taken but the information it contains must not be regarded as binding.

 HAWKER SIDDELEY

## PETTER DIESELS



Petters Limited, Service Division, Hamble, Southampton, SO3 5NJ England. Hamble 2061. Telex: 47626. Telegrams: Petter Hamble Telex  
 Southern Area Service Depot: Petters Ltd. Bridge Works, Staines, Middx TW18 3AR. Staines 51333.  
 Northern Area Service Depot: Petters Ltd. Broomhill Industrial Estate, Kirkintilloch, Dumbartonshire. Kirkintilloch 2316. Telex: 778204.

PRODUCED BY WATERMARK PRINTED IN ENGLAND 10/5/78